INSTRUCTIONS FOR USE OF PRODUCT E7061.



## **Startup**


- 1. Turn on the GloMax®-Multi Detection System Instrument (the switch is located on the back panel of the instrument).
- 2. The built-in PC and Windows® CE will load.
- 3. After warming up, the "Home" screen will appear.

### **Select a Protocol**

- 1. Set up a new protocol using the "New Protocol" wizard.
- -OR-
- 2. Select a saved protocol using the "Select Protocol" wizard.

## **Filter Wavelength Selections**

- 1. The six-position filter wheel holds four factory-installed filters and has two open filter positions for custom filters.
- 2. The four factory-installed filters are: 450, 560, 600, and 750nm.
- 3. Touch the "Wavelength Filter Selection" button(s) on the touch screen to select the proper filter.
  - See the *GloMax®-Multi Detection System Technical Manual #*TM297 for instructions in setting a reference wavelength.







INSTRUCTIONS FOR USE OF PRODUCT E7061.



### **Start A Run**

- 1. Touch the "Plate" button, and highlight the wells to be read (green wells are selected, pink wells are reference, and gray wells are deselected).
- 2. Touch the "Door" button to open the instrument. Place the microplate in the sample tray. Make sure the A1 well is at the top right corner.
- 3. If the Microplate Samples Tray Cover is installed, do not use force or push on to close it. The cover will close automatically.
- 4. Touch the "Start" button.
- 5. Touch the "Edit" button, and use the keypad to enter a file name.
- 6. Touch the "OK" button to start reading.

**Note:** To prevent evaporation and damage to the detector head, always remove the microplate when the read is complete.

### **Results**

#### To View Results

- 1. From the "Instrument Control" screen, touch the "Results" button.
- 2. Touch the "Files" button, and choose a saved file to view.

### To Transfer Results File(s)

- 1. Insert a USB flash drive into the USB port to the left of the touch screen.
- 2. Touch the "USB" button on the upper right corner of the screen.
- 3. Touch the "OK" button to export only the selected file, or touch the "Copy All Files" button to export all displayed and undisplayed results files.
- 4. Move the USB flash drive to a PC or Macintosh® computer to download files.

**Note:** Only the 50 most recent results files are displayed on the touch screen. All results files are stored on the internal memory of the instrument. To ensure that no data is lost, save your results files to a USB flash drive frequently.

For complete protocol information, see the *GloMax®-Multi Detection System Technical Manual #*TM297, available at: **www.promega.com/tbs** 



www.promega.com • Phone 608-274-4330 or 800-356-9526 • Fax 608-277-2601






INSTRUCTIONS FOR USE OF PRODUCT E7061.



## "Read" Screen Map




#### ORDERING/TECHNICAL INFORMATION:



INSTRUCTIONS FOR USE OF PRODUCT E7061.



## "Results" Screen Map



www.promega.com • Phone 608-274-4330 or 800-356-9526 • Fax 608-277-2601



